

## **Frame Material**

33mm Hardwood Timber

## **Tolerances**

Window frame to timber stud 10mm max Window frame to Masonry Wall 10mm max

## Fixing

Screw fix using 12 gauge screws at 400mm centres all four sides ensuring 30mm fixing into timber Fill wedging gap with Hilti CP606 or equivalent sealant

